












Isolation kits for steel/aluminium tunnels



















SE80 - SE/SH300 / Ø185mm - Ø300mm

- Thrusters with insulated aluminium bracket and pre-filled with oil:
- We recommend the aluminium tunnel to be coated with epoxy primer.
- Gearleg bolts in stainless steel must be insulated from the aluminium tunnel with a sleeve or equal for galvanic insulation.
- Brackets are in aluminium, so there is a risk for B+ connection to aluminium hull.
- We recommend an extra gasket as safety and insulation between bracket and tunnel.























Installation instructions

- 1. Use the standard drilling template or gasket to mark the centre of the holes on the tunnel correctly.
- 2. Use the correct and relevant isolator kit measurement drawing and drill the holes in accordance with measurements.
- 3. Place the isolator parts in position and fasten gearleg and bracket according to Thruster Instalation manual.

4.

IMPORTANT! Some isolation kits have a gasket included, remember always to place it between the tunnel and motor bracket.





This document may contain typographical errors and changes, to which Sleipner Motor assumes no responsibility.



Sleipner Motor AS P.O. Box 519, N-1612 Fredrikstad, Norway www.side-power.com

