

## 16 SYSTEM UPGRADE

The Dynamic Trim Control System software can be upgraded. Visit [www.zipwake.com](http://www.zipwake.com) to check for new software releases.

**⚠ IMPORTANT** The software upgrade file must be saved to the root of a USB memory stick with FAT32 formatting when upgrading the system.

1. Download a software upgrade file from [www.zipwake.com](http://www.zipwake.com).
2. Copy the software upgrade file to the root of the USB memory stick.
3. Remove the USB (A) connector cover on the back of the control panel and connect the USB memory stick to the DEVICE connector.
4. Restart the system and follow the instructions on the display.
5. Remember to remove the USB memory stick and put the connector cover back in place when done.



### NOTE!

Your System Configuration (user settings) and Auto Pitch Control Curve will not be erased when you upgrade to another software version. You can also downgrade to a previous software release.