


All sitting heights measured without load - a variation may occur depending on the load due to contraction of gas-struts, springs, upholstery and third part equipment. All information herein contained is subject to change without notice unless under contractual configuration control. Please consult Norsap if dimensions are critical or a certified drawing is required.

www.norsap.no

Chair interface:



Weight: 28.00



Mjåvannsvegen 45/47
NO 4626 Kristiansand (Norway)

Description:

NS800 STANDARD

Art.-No.:
6101

Date:
22.09.2020

Revision:
A 9