



All sitting heights measured without load - a variation may occur depending on the load due to contraction of gas-struts, springs, upholstery and third part equipment.
All information herein contained is subject to change without notice unless under contractual configuration control.
Please consult NorSap if dimensions are critical or a certified drawing is required.

www.norsap.no

Chair interface:



Weight: 97.66



Mjåvannsvegen 45/47
NO 4626 Kristiansand (Norway)

Description:

Norsap 1600 Standard S

Art.-No.:
8520

Date:
11.12.2019

Revision:
A 1