

PARTS:

SM321714 - Garmin GPS antenna
SMGWKIT - GW1 gateway, spur, backbone and "T"

INSTALLATION:

Turn off power to S-link
Find S-link leading to thruster panel or other device.
Disconnect blue backbone cable from T
Insert new T and short backbone & reconnect
Connect green spur cable to new T
Connect GW-1 Gateway to other end of Spur
Mount GW-1 gateway
Mount Garmin antenna
Connect Garmin antenna wires to NMEA0183 port as shown
Turn on power to S-link
Check if GPS VALID led is illuminated



SIDE-POWER STABILIZER ADD GPS & GW-1

imtra CORPORATION